












Quick Start Guide






**Thank you for purchasing
The Dos DM-270 from BRAVA**


See the complete user guide for more information and for important safety and maintenance information. Do not use this document instead of the complete user guide.

1. Getting to know your phone

-  G Send key (Left soft key) (1): Press to access **Answered calls** in standby mode; press G Send key and then immediately press * key to lock/Unlock the keypad; Making or answering a GSM call; used as "OK key" in some places; used as "Options" in some places...
-  Right soft key (2): Press to access **Contacts** in standby mode.
-  Navigation key (3): In standby mode, use four-way navigation key to access these shortcuts:
 -  Press up to access **Select network**.
 -  Press right to access **Messages**.
 -  Press down to access **Contacts list**.
 -  Press left to access **My shortcuts**. [The default is **Tools**].
-  OK key (4): Confirm the selection. Press to access Main menu in standby mode.
-  C Send/Talk key (5): Making or answering a CDMA call; Press to access **Dialed calls** in standby mode.



-  End key (6): End calls or reject calls. Close opened window and switch to idle screen.
- Press and hold  (7) to input "*, "P", "+*" in standby mode.
-  Radio key (8): Press and hold to turn Radio on in standby mode.
- Press and hold  (9) to enable Meeting mode in standby mode.
- Headset jack (10): Before using headset, pull in the headset to this hole.
- + - Side volume keys (11): Press to turn your volume up and down.
- USB/charger connector (12): Plug the travel adapter into the charger connector.
-  Power key(13): Press and hold to turn the phone on/off.



2. Insert the RUIIM/SIM card and battery


Insert the RUIIM/SIM card

1. With the back of the phone facing you, push down and slide the cover off in the direction shown.
2. Push the RUIIM/SIM card into the RUIIM/SIM card holder.



Insert and charge the battery

1. Align the gold-colored contacts of the battery with the battery compartment contacts and press the battery into place.
2. Replace the back cover by aligning the tabs and sliding the cover until it locks into place.
3. Plug the charger into a standard AC wall outlet.
4. Connect the USB data cable to the Charger connector.



3. Making phone call

When the mark for network operator appears in the display screen, then phone enter the idle screen, you can dial or answer calls.

- The indicate bar at the left and top corner of screen displays **GSM** and **CDMA** network signal intensity.
- The number can be dialed by multiple dialing modes from the idle screen, including: direct dialing by keypad and dialing from Messages/Call history/Contacts.

4. Dual-Standby mode

This handset supports dual-standby mode, which can support both GSM and CDMA network.

- It is more convenient for you to make the phone call and send message.
- You just need to choose one network before dialing or sending message.
- You can indicate whether the **GSM** and **CDMA** network used when roaming (outside your home network area) is searched automatically or manually.
- In the standby mode, press **OK Key** to access the **Main menu >Settings > Network settings> Select network**: To set net selection mode and select the network between card 1 and card 2.

5. Find additional support

BRAVA support options are flexible and comprehensive. Use the following resources to learn more about your new BRAVA DM-270.

BRAVA DM-270 user guide

Refer to the user guide for the most comprehensive details on how to use your new BRAVA DM-270.

BRAVA support on the web

Check **<http://www.bravatechno.com>** or your local BRAVA web site for the latest information.

Service provider

Contact your wireless service provider for questions regarding your wireless service.

- في وضع الاستعداد، اضغط **مفتاح موافق** للدخول إلى القائمة الرئيسية <الضبط> شبكة الجوال < اختيار الشبكة: وذلك لتحديد نمط اختيار الشبكة (بحث يدوي أو تلقائي) و كذا اختيار الشبكة سواء شبكة CDMA أو شبكة GSM.

5. المزيد من الدعم

خيارات الدعم من BRAVA مرنة و شاملة. استخدم المصادر التالية لتعرف المزيد من المعلومات عن هاتفك الجديد BRAVA DM-270.

دليل المستخدم BRAVA DM-270

يرجى الرجوع إلى دليل المستخدم للمزيد من التفاصيل الشاملة عن كيفية استخدام هاتفك الجديد BRAVA CS-570.


دعم BRAVA على الويب

يرجى زيارة موقعنا على الانترنت <http://www.bravatechno.com> لأخر المعلومات عن BRAVA.

مزود الخدمة

يرجى التواصل مع مزود الخدمة (مشغل الشبكة) اللاسلكية للاستعلام عن الخدمة اللاسلكية.

تركيب وشحن البطارية



1. قم بتطبيق نقاط الاتصال الذهبية الموجودة على البطارية مع منافذ التوصيل المقابلة في تجويف البطارية. ثم اضغط البطارية في التجويف المخصص لها.
2. اعد الغطاء الخلفي ثم أزرع الغطاء إلى أن ينطبق في مكانه المخصص.
3. قم بتوصيل جهاز الشاحن بمأخذ تيار متردد في الحائط.
4. قم بتوصيل كابل البيانات USB إلى فتحة الشاحن في الجهاز.

3. إجراء مكالمة هاتفية


عندما تظهر علامة مشغل الشبكة في شاشة الهاتف، عندها الهاتف يكون في وضع الاستعداد، حيث يمكنك إجراء اتصال أو الرد عليه.

- شريط الأيقونات في أعلى يسار الشاشة يعرض قوة الإشارة لكل من شبكة CDMA وشبكة GSM.
- يمكن الاتصال برقم معين بعدة طرق من شاشة الاستعداد، والتي تشمل التالي: الاتصال المباشر باستخدام لوحة المفاتيح والاتصال من الرسائل/سجل المكالمات/الأسماء.

4. وضع الاستعداد-الثاني

هذا الجهاز يدعم وضع الاستعداد الثاني، والذي يمكن أن يدعم كل من شبكة GSM و CDMA شبكة.

- أصبح من السهل عليك إجراء المكالمات الهاتفية وإرسال الرسائل.
- كلما تحتاجه هو اختيار الشبكة التي تريد قبل الاتصال.
- يمكنك تحديد أي شبكة سوف تستخدم للنموذج سواء CDMA أو GSM (عندما تكون خارج نطاق تغطية الشبكة الأم) وذلك بالبحث عنها إما يدويا أو تلقائيا.



الاستعداد للدخول إلى قائمة المكالمات الصادرة.

● مفتاح تشغيل/إنهاء (6): اضغط لإنهاء أو رفض المكالمات. لغلاق النافذة المفتوحة والرجوع إلى الشاشة الرئيسية (وضع الاستعداد).

● اضغط باستمرار (7) لإدخال اضغط لإدخال رمز "p", "x", "y", "z"

● مفتاح الراديو (8): في وضع الاستعداد اضغط باستمرار لتشغيل وضع الراديو الهاتف.

● اضغط باستمرار (9) لتفعيل وضع الاجتماع في وضع الاستعداد.

● منفذ سماعة الرأس (10): قبل استخدام سماعة الرأس، ادخل السماعة في هذا المنفذ.

● مفتاح +- الصوت الجانبي (11): لزيادة ونقص مستوى الصوت.

● منفذ USB/الشاحن (12): ادخل شاحن الهاتف الموجود في السيارة إلى منفذ الشاحن.

● مفتاح تشغيل/إنهاء (13): اضغط باستمرار لتشغيل/إيقاف تشغيل الهاتف.

2. إدخال بطاقة RUIIM/SIM مع البطارية



إدخال بطاقة RUIIM/SIM

1. اجعل خلف الهاتف مواجه لك، اضغط للأسفل و أزح الغطاء الخلفي في اتجاه السهم.
2. ادخل بطاقة RUIIM إلى حامل البطاقة.

1. معلومات عن الهاتف



● **مفتاح إرسال G** (مفتاح الاختيار الأيسر)

(1): في وضع الاستعداد اضغط **مفتاح إرسال G**

للوصول إلى المكالمات الواردة. أو اضغط **مفتاح إرسال G** ثم اضغط مباشرة مفتاح (*) لقفّل/الغاء قفّل لوحة المفاتيح.

يستخدم لإجراء مكالمات GSM أو الرد عليها، كما يستخدم كـ "مفتاح موافق" في بعض الأحيان، و "خيارات" في أحيان أخرى.

● **مفتاح الاختيار الأيمن (2):** في وضع

الاستعداد، اضغط المفتاح للوصول إلى قائمة **الاسماء**.

● **مفتاح التنقل (3):** في وضع الاستعداد،

استخدم مفتاح التنقل ذو الاتجاهات الأربعة للوصول إلى هذه الاختصارات.

● اضغط المفتاح **أعلى** للوصول إلى **مشغل**

الموسيقى.

● اضغط المفتاح **يمين** للوصول إلى **الرسائل**.

● اضغط المفتاح **أسفل** للوصول إلى قائمة **الاسماء**.

● اضغط المفتاح **يسار** للوصول إلى **متصفح الويب**.

● اختر المفتاح (4): اضغط للدخول إلى القائمة الرئيسية في وضع الاستعداد.

● مفتاح إرسال/تحديث C (5): اضغط لإجراء مكالمات CDMA أو الرد عليها. وفي وضع



دليل التشغيل السريع

شكرا لافتنائكم هاتف
BRAVA من Dos DM-270

انظر إلى دليل المستخدم الكامل للمزيد من المعلومات وللمزيد من تعليمات الأمان الهامة والصيانة. لا تستعمل هذا المستند بدلا من دليل المستخدم الكامل.